

Max Air



Channel Strip

Group
1 2 3 4 5 6 7 8
9 10 11 12 13 14 15 16
17 18 19 20 21 22 23 24

Aux
1 2 3 4 5 6 7 8
9 10 11 12

Mix
A B C D E F G H

Knobset
Select *

Ins Inp

Dyn

EQ

In Out Filt

Aux Pan

Mix Group

Mix- Bus

48v

Select On

Input

Select On

PanF

Select On

Gain

Select On

Copy Paste

Talk

Swap Channel

Main Channel

Chan Select

On

Select M S L

48V ↕ 12 ●
Lock ST
Mix- ↕ 6 ●

0 ▶ ◀

6 ●

12 ●

18 ▶ ◀

24 ●

30 ●

36 ●

42 ●

48 ●

60 ●

72 ●

∞ ●

12-Jul-02



digital emotion

www.euphonix.com